



BRIGGS AND STRATTON ENGINE START-UP

To start any



follow these simple steps:

(1) Locate the 'ON/OFF' switch (usually the 'BOTTOM LEVER') and turn to the 'ON' position OR the 'RABBIT' position



(2) Locate the 'CHOKE' and put in the 'ON' position



(3) Give the engine's pull cord ONE pull



(4) Move the 'CHOKE LEVER' to the 'RUN' position and give the engine's pull cord ONE pull





BRIGGS AND STRATTON ENGINE START-UP

PAGE (2)

- (5) THIS IS THE MOST IMPORTANT STARTING INSTRUCTION!!! Repeat steps (2) to (4) until the engine starts. Once the engine has started, make sure that the 'CHOKE LEVER' is in the 'RUN' position.
- (6) ENGINE SHUTDOWN: Move the 'ON/OFF' switch to the 'OFF' position.

**DO NOT PULL THE CORD ON THIS ENGINE WITH THE CHOKE IN THE 'ON' POSITION
MORE THAN THREE TIMES!!!
YOU MUST ALTERNATE BETWEEN THE 'CHOKE' AND 'RUN' POSITION
IF YOU DETECT THE SMELL OF GAS, STOP WHAT YOU ARE DOING!!!
CALL US IMMEDIATELY!!!**