

STIHL (2-CYCLE) ENGINE START-UP

To start any:



follow these simple steps:

(1) Locate the 'ON/OFF' switch and move to the 'ON' position



(2) Locate the 'CHOKE LEVER' and move it to the full 'ON' position. Note that for some Stihl model chainsaws you may have to squeeze the throttle lever to move the choke to this position. The throttle may now be locked into the full on position.
MAKE SURE THE CHAINBRAKE IS IN THE FULL 'ON' POSITION!!!! THIS IS DONE BY PUSHING THE CHAINBRAKE FORWARD TOWARDS THE CHAINBAR UNTIL YOU HEAR A 'CLICK'



STIHL (2-CYCLE) ENGINE START-UP PAGE (2)

- (3) Pull the cord until the engine 'SPUTTERS' (starts to run and then stalls)
PLEASE NOTE: NO STIHL ENGINE SHOULD SPUTTER ON THE FIRST PULL. THIS IS WHAT WE CALL A "TEASER"! IF THIS HAPPENS, IMMEDIATELY MOVE TO STEP (4), THEN GIVE THE ENGINE'S PULL CORD 2 OR 3 PULLS, THEN GO BACK TO STEP (2) AND PROCEED AS OUTLINED.



- (4) Move the 'CHOKE LEVER' to the full 'OFF' position



- (5) Pull the cord until the engine starts.
- (6) ENGINE SHUTDOWN: Locate the 'ON/OFF' switch and move to the 'OFF' position.

**IF YOU DETECT THE SMELL OF GAS, STOP WHAT YOU ARE DOING!!!
CALL US IMMEDIATELY!!!**